

変更内容 Version 1.0.1→ 1.0.2

1.使用許諾書の更新

ソフトウェア使用許諾書の内容変更

2.API 仕様書の更新

API 仕様書の内容追記

3.サンプルコードの追加

オンラインで偏光処理、描画までするサンプルコード(C#)を追加

Change contents from the version "1.0.1" to "1.0.2"

1.Update "End User License Agreement"

Contents change of "End User License Agreement"

2.Update API specifications

Contents addition of API specifications

3.Add a sample program

Added a sample program for C# which shows how to implement receiving images from camera, polarization process and displaying the results.

#####

既知問題 Version 1.0.2

1.サンプルプログラムで参照する DLL 名称が正しくない

【修正方法】

exe 側の NativeMethods.cs で参照されている DLL 名称を修正

- XPL-SDKW¥examples¥OnlineVS2017¥XPLSampleCS¥Common¥NativeMethods.cs

[誤] DllImport("XPLSample3Native.dll")

[正] DllImport("XPLSampleNative.dll")

Known Issues on version "1.0.2"

1.DLL name to refer to in the sample program isn't correct.

【Correction method】

It corrects the DLL name referred to in NativeMethods.cs of the exe program code.

- XPL-SDKW¥examples¥OnlineVS2017¥XPLSampleCS¥Common¥NativeMethods.cs

[Now] DllImport("XPLSample3Native.dll")

[Corrected] DllImport("XPLSampleNative.dll")